

Item	Spare ID	Description	Qty
1	502401000386	Power cord	1
2	502500100003	Topping Screw	4
13	501111240003	Cabinet	1
14	502500100069	Topping Screw BL112WH	2
15	501108330013	Top Cover Link Button BL112WH	2
16	502905040039	Top Hinge BL112WH	1
18	502408000009	Light Switch BL112WH	1
19	50290504001N	Hinge And Adjustable Foot BL112WH	1
21			
22	501113040001	Adjustable Leg BL112WH	1
23	501112040033	Lamp Shade BL112WH	1
24	501112040062	Thermostat Box BL112WH	1
25	502410000087	Lamp BL112WH	1
26	502409000051	Lamp Holder BL112WH	1
27	50240700000H	Thermostat BL112WH	1
28	50111244000D	Thermostat Knob BL112WH	1
30	50360104000F	Glass Shelves BL112WH	2
32	50360204001C	Glass Shelves BL112WH	1
33	501111240032	Vegetable Box BL112WH	1
35	501112840001	Washer BL112WH	1
36	501123110005	Hinge Shaft Sleeve BL112WH	1
39	501111240007	Gasket BL112WH	1
41	501111240006	Door Stopper BL112WH	1
42	502500300010	Screw BL112WH	1
43	501111240031	Upper Glass Rim BL112WH	2
44	501111240030	Down Glass Rim BL112WH	1
45	503700140318	Door BL112WH	1
46	503705040332	Cabinet	1

